




ILLUSTRATED PARTS LIST

SL WINDOW AWNING

SL WINDOW AWNING ILLUSTRATED PARTS LIST



SL501

Item	Part Number	Description	Notes
1	R001181	Bracket, Arm Mount	
2	R038124-15XXX	Arm	Standard
	R038124--27XXX	Arm	XL
3	R001182XXX	Head and Spring Assy, RH	3' - 8' 2
	R001184XXX	Head and Spring Assy, RH	8'1" 13' 2
	R001172XXX	Head and Spring Assy, RH	13' 1" - 15' 2
4	R001183XXX	Head and Spring Assy, LH	3' - 8' 2
	R001185XXX	Head and Spring Assy, LH	8'1" 13' 2
	R001171XXX	Head and Spring Assy, LH	13' 1" - 15' 2
5	R047042-001	Bumper	
6	R022406-028	Pull Strap, 28"	Standard
	R022406-043	Pull Strap, 43"	XL
7	901044	Pull Strap Catch, Black	(2 per pkg)
	901044W	Pull Strap Catch, White	(2 per pkg)
8		Roller Tube	See Hardware and Accessories
9		Canopy Only	Refer to Canopy Order Form
10		Awning Rail	See Hardware and Accessories
11	R001202XXX-xxx	Uniguard w/Soft Connect	
12	R001248XXX-xxx	Soft Connect (only)	
13	R019774-005	Hardware Pack	White
	R019774-006	Hardware Pack	Black

- Notes: 1. XXX = Color; xxx = Length
 2. Spring assemblies (items 3, 4) are available in WHT (white) for white arms, BLK (black) for all other colors.