

Legacy Roller Shade Installation Manual

Please verify the following before beginning the installation,:

1. The valance box is at least 2.5" deep, measure depth from the inside of the sideboard to the wall.
2. The width of the shade is greater than the window and less than the window valance.

Installation Instructions

Remove the old shade and mounting brackets

Inside the Legacy Shade box you will find all the materials required for the installation.

1. Mount the top bracket by screwing it to the top inside wall of the valance using the supplied screws. The center of the bracket must be aligned with the center of the valance.
2. Once the bracket is securely fastened to the top of the valance box, the Inside shade cassette is installed by hooking the lead rail to the top mounting bracket.

Shade operation:

For Combo Rollers

Turn the valance over and operate each shade looking at the back of the valance box. If additional tension is needed or the stop (height) needs adjusting see steps below.

Day shade (Lower Roller), turn the BLACK adjustment knob on the RIGHT SIDE COUNTER CLOCKWISE one turn. Recheck tension, if more tension is needed add additional turns to desired tension. To adjust the height the roller stops, turn the WHITE adjustment knob on the LEFT side until the grab bar stops at the appropriate height.

Night Shade (Upper Roller) turn the BLACK adjustment knob on the LEFT SIDE CLOCKWISE one turn. Recheck tension, if more tension is needed add additional turns to desired tension. To adjust the height the roller stops turn the WHITE adjustment knob on the RIGHT side until the grab bar stops at the appropriate height.

Be sure there are no obstructions that the grab bar would touch.

If you prefer to remove only your old shades, leaving the valance in place, mount the clips as instructed above. Snap the lead bar into the clips and adjust the height and tension as outlined above. Note: the tension and the height adjusters will be on the other side.

For Single Rollers

Turn the valance over and operate each shade looking at the back of the valance box. If additional tension is needed or the stop (height) needs adjusting see steps below.

Turn the BLACK adjustment knob on the RIGHT SIDE COUNTER CLOCKWISE one turn. Recheck tension, if more tension is needed add additional turns to desired tension. To adjust the height the roller stops turn the WHITE adjustment knob on the LEFT side until the grab bar stops at the appropriate height.

Be sure there are no obstructions that the grab bar would touch.

If you prefer to remove only your old shades, leaving the valance in place, mount the clips as instructed above. Snap the lead bar into the clips and adjust the height and tension as outlined above. Note: the tension and the height adjusters will be on the other side.



For Power Rollers

- Please read all the instructions once before starting.
- To realize this operation you will need a 3/32 flat screw driver or smaller.
- This procedure will guide you to adjust the top and bottom shade position.
- Before starting the process make sure your shade is rolled up as much as possible.

To adjust the Power Roller shades you first have to locate the motor, (motor position varies depending on installation needs). Once you located the motor you need to find the rectangular hole that's on the side of the power wiring in the motor head.

To start the process press DOWN, as the shade is moving down using your 3/32 screw driver press the motor button for 3 second, the motor will stop and beep 3 times to let you know it has entered to setup mode, once you hear the 3 beeps take your screw driver off the button and the shade will continue to move down, once it gets close to the bottom limit release the DOWN button, the shade will stop and then you can fine tune the position by tapping the DOWN button. When you get to the desired position press the UP button, the motor will beep 3 times to let you know you have set your bottom position and will keep rolling up, once you get to close to the top position let the UP button go and fine tune it by tapping it, when you get to the desired position press the DOWN button, the motor will beep 3 times to let you know you have setup the top limit.

